


Deep sleep wakeup with the optional remove tool:

There is an optional Keytool available to remove the enclosure from the click mount.



Assembled devices:

When you order a fully assembled device, the unit is in deep sleep mode on arrival. To wakeup the device you have to use the keytool (optional) with a magnet inside. If you swipe the keytool (with the magnet pointed to the housing) a few times at the top side of the enclosure from left to right and back, the device will wake up and will start to make a connection.

All leds start to blink when it is done successful.



See also this video that shows the wakeup procedure: <https://www.1m2m.eu/videos/>